

# BEDLOCKER®

## Electric Retractable Tonneau Cover

### Electronics Box Programming Instructions

1. Plug the 4-wire connectors together and make sure power is connected.
2. Hold the electronics box upside down and pull the small rubber plug out of the hole situated between the wires at the bottom of the box.
3. Using a narrow beam flashlight, point the beam straight in the small hole. Count out 4 seconds on the hole, then remove for 4 seconds, then 4 seconds on the hole, then remove for 4 seconds. It takes two cycles to program and there is a rhythm to it.\* (You may need to try it a couple of times to get it to program correctly.) If you have done it correctly the canister light will blink one time to indicate that it is in program mode.
4. Once in program mode you will need to push and release the upper left button (lock symbol) on the (un-programmed) remote to store the transmitter code in the box for each 4-button remote that you have. The light will blink two times for each remote that you program in to the box. The two blinks let you know that the transmitter was recognized.
5. When you're done programming the transmitters let the unit sit without activating any other transmitters for 30 seconds. After 30 seconds the light will blink again three times to notify you that it is no longer in the program mode.
6. Your unit should operate at this time.
7. Replace the rubber plug into the optical programming hole when done.
8. To reactivate the programming sequence simply start over again with the flashlight and follow the steps above starting with step two.
9. **After you are done programming the unit, mount the electronics box up under the bed rail with the wires hanging out the bottom of the box. This will prevent water from seeping into and malfunctioning the electronics box.**

*\*Keep in mind that your first try may not activate the electronics box into program mode. You may have to try it a few times to figure out the right length of time to hold and remove the flashlight.*

*Please contact Pace Edwards Technical Support if you have any questions. (800) 338-3697*

**Thank you for purchasing**  **products**